<u>Aim</u>

The aim of this experiment is to investigate the relationship between the current, voltage and resistance through the use of a fixed resistor and a filament lamp.

Hypothesis

Based on knowledge of Ohm's law it can be hypothesised that when an increasing voltage and current is passed through a filament lamp the resistance would increase in an irregular fashion, so that a graph similar to the one given below would be seen (figure 1). This curved graph would be expected due to temperature increases in the filament lamp.

It can also be hypothesised that when current is passed through a fixed resistor a straight line graph would be obtained (figure 2) this is explained in figure 3.




Figure 1: Current Voltage graph for filament lamp. (Taken from GCSE Physics revision guide).




Figure 2: Current Voltage graph for fixed resistor. (Taken from GCSE Physics revision guide).

Figure 3 my rationale for why current will rise with voltage

$$I \text{ (Cinert } Appaes) = \frac{V \text{ (Vitage Vits)}}{R \text{ (Resistanc } e \Omega)}$$

$$V = incessing = 1, 2, 3$$

$$R = constant = 1\Omega$$

$$\therefore I = \frac{IV}{1\dot{U}} = IA$$


$$\Rightarrow I = \frac{2V}{1\dot{U}} = 2A$$


$$\Rightarrow I = \frac{3V}{1\dot{U}} = 3A$$

 \therefore with a constant resistance $(1\,\Omega)$ and inversing voltage the current inverses

too

Circuit Diagrams





Equipment

Fixed resistor & Filament Lamp— Ammeter—

to impede and obstruct current flowing through circuit to measure current flowing through the circuit

Abdul Mufti Centre Number: 13329 Candidate Number: 4138

Voltmeter— to measure the voltage present in the circuit and to make sure the power supply

is correctly calibrated.

Power Supply— to act as the adjustable power source for the circuit

Wires— to connect the circuit components. Tangles were removed from the wires as not doing so could result in erroneous values being obtained in the experiment, as using several different wires or tangled wires during the experiment could lead to varied resistance and poor fair test (Figure 6).




Figure 6: Current Voltage graph for different wires. (Taken from GCSE Physics revision guide).

Safety Precautions

Bags stools and other possible obstructions were removed from gangway. Worktops were cleaned and dried to reduce risk of electrocution and prevent damage or interference to experimental equipment. Standard lab safety was enforced. In order to keep errors to minimum and to ensure fair test, equipment such as wires, voltmeters, ammeters, resistors, PSU's and filament lamps remained the same throughout the experiment.

Method

The work surface was ensured to be dry and clean beforehand. Bags, stools and other possible obstacles were removed from the work area. The equipment was collected according to the list given and was checked to be clean, non-corroded and undamaged. The equipment was connected as is shown in figure 4. It was not turned on until connections were checked to be correct and safe and settings on the power supply and meters were at their lowest. Writing equipment was in place before the experiment was started.

The equipment was then turned on. As the voltage on the PSU was increased it was confirmed on the voltmeter and the reading on the ammeter was noted. For the first circuit a total of 7 ammeter readings were taken and repeated. Each time the voltage was increased by 2 V.

The value for each voltage was recorded in the table. Once the highest voltage had been reached for the PSU the circuit was switched off and the fixed resistor was replaced with a filament lamp (figure 6). The voltage readings were then repeated as before and were inserted in another table. After this the equipment was cleared away. The tables were then plotted onto graphs.

Method in summary:

- 1. Apply safety precautions.
- 2. Gather equipment and connect it according to figure 4.
- 3. Recheck for safety and turn the circuit on.
- 4. Increase the Voltage by 2V every reading and note the current reading on the ammeter.
- 5. Once 12V is reached switch the PSU off.
- 6. Replace resistor with a Filament Lamp
- 7. Carry out steps 3-5 again.
- 8. Once readings for filament lamp and fixed resistor are tabulated clear up equipment.
- 9. Plot an I-V graph for the fixed resistor and Filament Lamp.

Variables

The controlled variables in this experiment are the resistors and equipment used.

The input variable in this experiment is the voltage.

The output variables of this experiment are the current and resistance.

Tables of results

Table 1 Circuit with fixed resistor	
Voltage (V)	Current (A)

Abdul Mufti 10. F

Centre Number: 13329 Candidate Number: 4138

0.00	0.00
2.10	0.20
4.10	0.44
6.20	0.58
7.90	0.71
10.00	0.92
12.10	1.10

Table 2 Circuit with filament lamp				
Voltage (V)	Current (A)			
0.00	0.00			
1.00	0.46			
2.00	0.74			
4.00	1.10			
6.20	1.36			
8.30	1.54			
10.20	1.66			
12.10	1.74			

Calculation 1 Resistance calculation for the fixed resistor.

$$V = IR \implies R = \frac{V}{I} = \frac{\ddot{A}V}{\ddot{A}I} = \frac{\Delta x}{\Delta y}$$

$$\Rightarrow R = \frac{\Delta x}{\Delta y} = \frac{1300V}{119A} - \frac{000V}{-000A} = 10.92 \Omega$$

:. Resistance of fixed resistor is 1092 $\Omega \approx 11~\Omega$

Table	7	Circ	:.	طاختيير	fived	rosistor
Table	3	Circ	uit	with	rixea	resistor

Point of graph gradient measured

Throughout experiment

Resistance (Ω) $(10.92) \sim 11$

$$V = IR \implies R = \frac{V}{I} = \frac{\ddot{A}V}{\ddot{A}I} = \frac{\Delta x}{\Delta y}$$

$$\Rightarrow R(at \quad point \quad a) = \frac{\Delta x}{\Delta y} = \frac{200V - 000V}{080A - 010A} = 2.86 \Omega$$

$$\Rightarrow R(at \quad point \quad b) = \frac{\Delta x}{\Delta y} = \frac{600V - 200V}{140A - 008A} = 6.67 \Omega$$

$$\Rightarrow R(a \quad pirt \quad b) = \frac{\Delta x}{\Delta y} = \frac{600V - 200V}{140A - 008A} = 6.67 \Omega$$

$$\Rightarrow \text{Ret} \quad \text{point} \quad \phi = \frac{\Delta x}{\Delta y} = \frac{1400V - 810V}{180A - 160A} = 32.7\Omega$$

∴ Restance of filanent $and point a is \approx 3\Omega$

∴ Resistance of filanent $tanp at point b is \approx 7\Omega$

∴ Resistance lamp at point c is $\approx 33 \Omega$ of filament

Table 4 Circuit with fixed resistor			
Point of graph gradient measured	Resistance (Ω)		
A	2.86		
В	6.67		
С	32.70		

Analysis of Results

Both graphs produced results that should be expected by the types of resistor used. The graph for the fixed resistor is a straight line through the origin. The slope of the line was unchanged i.e. no tapering off. This is what should be observed when fixed resistors are used. The current value for 4.1V is more than was expected; it may be classed as an anomaly but does not affect the line of best fit too much. The reason for this value may be down to poorly calibrated equipment or incorrect reading from the ammeter i.e. human error. The remainder of the current readings fit the expected trend. The hypotheses for the fixed resistor which was:

When current is passed through a fixed resistor a straight line graph would be obtained

On the graph for the filament lamp the curve of best fit suggests that resistance increases as voltage and current are increased. This is shown by the resistance values from the three gradients taken from the indicated tangents (Table 4). The gradient calculated at each of the three points was different and the resistance value was also increased. This occurs due to an increase in temperature of the filament lamp. This also confirms my hypotheses as being correct.

- ➤ When current is passed through a filament lamp the resistance would increase in an irregular fashion.
- ➤ So that a curved graph would be produced due to temperature increases.

Results for both resistors were as expected based on scientific knowledge of Ohm's law and how resistance is affected by V, I and temperature. All parts of the hypotheses were confirmed to be correct and supported by the results that were obtained.

Conclusion

Looking at the graphs and the table of results it is clear that what I hypothesised at the beginning of the experiment was correct correct:

Abdul Mufti Centre Number: 13329 Candidate Number: 4138 10. F

When current is passed through a fixed resistor a straight line graph would be obtained

When current is passed through a filament lamp the resistance would increase and a curved

graph would be produced.

The curve and straight line graphs prove that there is a relationship between the resistance, current

and voltage. When V increases I increases too, as long as resistance stays constant (for fixed resistor)

or increases (for filament lamp). Also as the temperature increases the resistance increases, as is

observed with the filament lamp.

Evaluation

The experiment was successful in its aims. The experiment was also successful since there were few

anomalies, only one for the fixed resistor. Thus it can be assumed that our results were accurate given

the sensitivity of our equipment. We tried to resolve these anomalies by doing these tests again,

however this resulted in getting the same figure. We can assume that the equipment is not to blame

since it was kept the same throughout the experiment. The experiment was conducted in a safe

environment and all precautions taken before the experiment paid off as no accidents took place.

To conduct a fair test it would have been practical to use averages for a series of current readings.

This could be done by using two different sets of equipment, conducting the experiment on each set

and averaging the values. This could help us reduce the margin of error in any anomalies found. It

may have been interesting to investigate the same aim with a wider range and more sensitive set of

equipment. Smaller increases of voltage on the PSU would have allowed us to plot the graphs with

more accuracy. If possible it would have been interesting to use a diode. We may also have adjusted

variables such as the thickness, length and type of wire used to investigate the effect these factors

have on Ohm's law and our graphs. we would also investigate how changing the circuit diagram

would have affected our results.

However it would not have been possible because of time limitations

Bibliography

GCSE double Science Physics – CGP – ISBN: 1-84146-401-5

New Modular Science for GCSE, (Vol 1), - Heinemann (1996) – ISBN: 0-43557-196-6

7

Abdul Mufti Centre Number: 13329 Candidate Number: 4138 10. F

AQA GCSE Science syllabus (2001).

A level Physics Letts Study Guide (reprinted 1996)